


## 19. Exploded View and Replacement Parts List

### 19.1 Indoor Unit



**Note:**

- The above exploded view is for the purpose of parts disassembly and replacement.
- The non-numbered parts are not kept as standard service parts.

<Model: WH-SDC09H3E8 >

| SAFETY | REF. NO. | DESCRIPTION & NAME                    | QTY. | WH-SDC09H3E8 | REMARK |
|--------|----------|---------------------------------------|------|--------------|--------|
|        | 1        | BASE PAN                              | 1    | CWD521450    |        |
|        | 2        | HOT WATER COIL - COMPLETE             | 1    | ACXB90C00220 |        |
|        | 3        | RECEIVER                              | 1    | CWB141039    |        |
|        | 4        | CATCHER                               | 2    | CWH601011    |        |
|        | 5        | FLARE NUT (5/8)                       | 1    | CWT251064    |        |
|        | 6        | FLARE NUT                             | 1    | CWT251061    |        |
|        | 7        | FLARE NUT (1/4)                       | 1    | CWT251063    |        |
|        | 8        | WATER PUMP                            | 1    | CWB532116    | O      |
|        | 9        | FERRITE CORE                          | 1    | CWA431122    |        |
|        | 10       | LEAD WIRE - FOR PUMP                  | 1    | ACXA60C06140 | O      |
|        | 11       | PRESSURE RELIEF VALVE                 | 1    | CWB621136    | O      |
|        | 12       | FILTER COMPLETE                       | 1    | CWB51C1021   |        |
|        | 13       | FLOW SENSOR                           | 1    | CWB621137    | O      |
|        | 14       | PRESSURE GAUGE                        | 1    | CWB070003    |        |
|        | 15       | HEATER ASS'Y                          | 1    | ACXA34K00080 | O      |
|        | 16       | SOUND PROOF MATERIAL                  | 1    | ACXG30-00680 |        |
|        | 17       | AIR PURGE VALVE                       | 1    | ACXB62-00130 | O      |
|        | 18       | THERMOSTAT                            | 4    | CWA151074    | O      |
|        | 19       | CONTROL BOARD                         | 1    | CWH102629    |        |
|        | 20       | ELECTRONIC CONTROLLER - MAIN          | 1    | ACXA73C11510 | O      |
|        | 21       | TERMINAL BOARD ASS'Y (1 TO 5)         | 1    | CWA28K1240   | O      |
|        | 22       | TERMINAL BOARD ASS'Y (A, B)           | 1    | CWA28K1260   | O      |
|        | 23       | REACTOR                               | 1    | G0C103Z00003 | O      |
|        | 24       | HINGE                                 | 2    | CWH611006    |        |
|        | 25       | HINGE                                 | 2    | CWH611007    |        |
|        | 26       | RESIDUAL CURRENT CIRCUIT BREAKER      | 1    | CWA181008    | O      |
|        | 27       | RESIDUAL CURRENT CIRCUIT BREAKER      | 1    | K5KYYAY00003 | O      |
|        | 28       | SENSOR - CO. (WATER IN, OUT REF TEMP) | 1    | CWA50C3377   | O      |
|        | 29       | SENSOR - CO. (HEX WATER OUTLET)       | 1    | CWA50C3378   | O      |
|        | 30       | REMOTE CONTROL COMPLETE               | 1    | CWA75C4681   | O      |
|        | 31       | CABINET SIDE PLATE                    | 2    | CWE041850A   |        |
|        | 32       | CABINET FRONT PLATE                   | 1    | CWE061396A   |        |
|        | 33       | LOCK                                  | 2    | CWH891004    |        |
|        | 34       | DECORATION BASE ASS'Y                 | 1    | CWE35K1285   |        |
|        | 35       | ACCESSORY - COMPLETE                  | 1    | CWH82C2174   |        |
|        | 36       | INSTALLING HOLDER                     | 1    | CWH361103A   |        |
|        | 37       | OPERATING INSTRUCTION                 | 1    | ACXF55-02060 |        |
|        | 38       | OPERATING INSTRUCTION                 | 1    | ACXF55-02070 |        |
|        | 39       | OPERATING INSTRUCTION                 | 1    | ACXF55-02090 |        |
|        | 40       | OPERATING INSTRUCTION                 | 1    | ACXF55-02100 |        |
|        | 41       | OPERATING INSTRUCTION                 | 1    | ACXF55-02110 |        |
|        | 42       | INSTALLATION INSTRUCTION              | 1    | ACXF60-03130 |        |
|        | 43       | INSTALLATION INSTRUCTION              | 1    | ACXF60-03260 |        |
|        | 44       | BAG - COMPLETE (FLEXIBLE PIPE)        | 1    | CWG87C900    |        |
|        | 45       | INSTALLING HOLDER                     | 1    | CWH361119A   |        |
|        | 46       | ACCESSORY - COMPLETE                  | 1    | CWH82C1754   |        |

**Note:**

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.