
# 19. Exploded View and Replacement Parts List

## 19.1 WH-SHF09F3E8 WH-SHF12F9E8



#### Note:

- The above exploded view is for the purpose of parts disassembly and replacement.
- The non-numbered parts are not kept as standard service parts.

#### < Model: WH-SHF09F3E8 WH-SHF12F9E8>

| SAFETY      | REF. NO. | DESCRIPTION & NAME                                | QTY. | WH-SHF09F3E8 | WH-SHF12F9E8 | REMARK |
|-------------|----------|---|------|--------------|--------------|--------|
|             | 1        | BASE PAN  | 1    | CWD521266    | <b>←</b>     |        |
|             | 2        | HOT WATER COIL - COMPLETE                         | 1    | CWB90C1088   | <b>←</b>     |        |
|             | 3        | RECEIVER  | 1    | CWB141039    | <b>←</b>     |        |
|             | 4        | FLOW SWITCH                                       | 1    | CWB621128    | <b>←</b>     |        |
|             | 6        | FLARE NUT (5/8)                                   | 1    | CWT251064    | <b>←</b>     |        |
|             | 7        | FLARE NUT (1/4) (3/8)                             | 1    | CWT251063    | <b>←</b>     |        |
|             | 9        | WATER PUMP  | 1    | CWB532116    | <b>←</b>     |        |
|             | 10       | PACKING (O-RING) I.D 32mm                         | 2    | CWB811082    | <b>←</b>     |        |
|             | 13       | PRESSURE RELIEF VALVE                             | 1    | CWB621092    | <b>←</b>     |        |
|             | 14       | RETAINING RING D:22mm                             | 2    | CWH581007    | <b>←</b>     |        |
|             | 16       | BOTTLE COMPLETE                                   | 1    | CWH90C0050   | CWH90C0049   |        |
|             | 17       | HEATER ASS'Y                                      | 1    | CWA34K1042   | CWA34K1030   | 0      |
|             | 18       | SOUND PROOF MATERIAL                              | 1    | CWG302835    | CWG302853    |        |
|             | 19       | THERMOSTAT  | 4    | CWA151074    | <b>←</b>     | 0      |
| <u>^</u>    | 20       | ELECTRONIC CONTROLLER - MAIN                      | 1    | CWA73C8310   | CWA73C8311   | 0      |
| $\triangle$ | 21       | TERMINAL BOARD ASS'Y (TO OUTDOOR UNIT)            | 1    | CWA28K1240   | <b>←</b>     | 0      |
| $\triangle$ | 25       | TERMINAL BOARD ASS'Y (TO 2, 3 WAY VALVE)          | 1    | CWA28K1229   | ←            | 0      |
| $\triangle$ | 26       | TERMINAL BOARD ASS'Y (TO HEATER, ROOM THERMOSTAT) | 1    | CWA28K1230   | <b>←</b>     | 0      |
| <u> </u>    | 28       | TERMINAL BOARD ASS'Y (TO TANK)                    | 1    | CWA28K1231   | ←            | 0      |
|             | 29       | RESIDUAL CURRENT CIRCUIT BREAKER                  | 1/2  | CWA181008    | ←            | 0      |
|             | 29a      | RESIDUAL CURRENT CIRCUIT BREAKER                  | 1    | K5KYYAY00003 | -            | 0      |
|             | 30       | TRANSFORMER - COMPLETE                            | 1    | CWA40C1096   | ←            | 0      |
|             | 31       | SENSOR - CO. (WATER IN, OUT, REF TEMP SENSOR)     | 1    | CWA50C2762   | ←            | 0      |
|             | 31a      | SENSOR - CO. (HEX WATER OUTLET)                   | 1    | CWA50C3164   | <b>←</b>     | 0      |
|             | 32       | REMOTE CONTROL COMPLETE                           | 1    | CWA75C4425   | ←            | 0      |
|             | 33       | PRESSURE GAUGE                                    | 1    | CWB070001    | ←            | 0      |
|             | 34       | AIR PURGE VALVE                                   | 1    | CWB621094    | <b>←</b>     | 0      |
|             | 35       | CABINET   | 1    | CWE001050A   | <b>←</b>     |        |
|             | 36       | HANDLE  | 2    | CWE161008    | <b>←</b>     |        |
|             | 37       | CABINET FRONT PLATE                               | 1    | CWE061265A   | ←            |        |
|             | 38       | INSTALLING HOLDER                                 | 1    | CWH361103A   | ←            |        |
|             | 38a      | INSTALLING HOLDER                                 | 1    | CWH361119A   | ←            |        |
|             | 39       | OPERATING INSTRUCTION                             | 1    | CWF569378    | <b>←</b>     |        |
|             | 39a      | OPERATING INSTRUCTION                             | 1    | CWF569379    | <b>←</b>     |        |
|             | 40       | INSTALLATION INSTRUCTION                          | 1    | CWF616147    | <b>←</b>     |        |
|             | 42       | ACCESSORY - COMPLETE                              | 1    | CWH82C1754   | <b>←</b>     |        |
|             | 43       | CONTROL BOARD                                     | 1    | CWH102409    | <b>←</b>     |        |
| <u> </u>    | 46       | REACTOR   | 1    | G0C103Z00003 | <b>←</b>     | 0      |
|             | 47       | TERMINAL COVER (HEATER)                           | 1    | CWH171052    | <b>←</b>     |        |
|             | 48       | TERMINAL COVER (THERMOSTAT)                       | 1    | CWH171051    | ←            |        |
|             | 49       | BAG   | 1    | CWG861447    | ←            |        |
|             | 50       | BASE BOARD - COMPLETE                             | 1    | CWG62C1124   | ←            |        |
|             | 51       | SHOCK ABSORBER                                    | 1    | CWG713189    | ←            |        |
|             | 52       | C.C.CASE  | 1    | CWG568364    | ←            |        |

### Note:

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.