


19 Exploded View and Replacement Parts List

19.1. WH-SXC09D3E5 WH-SXC12D6E5



Note:
The above exploded view is for the purpose of parts disassembly and replacement.
The non-numbered parts are not kept as standard service parts.

<Model: WH-SXC09D3E5 WH-SXC12D6E5>

REF. NO.	DESCRIPTION & NAME	QTY.	WH-SXC09D3E5	WH-SXC12D6E5	REMARKS
1	BASE PAN	1	CWD521279	←	
2	HOT WATER COIL-COMLETE	1	CWB90C1051	←	O
3	RECEIVER	1	CWB141039	←	
4	FLOAT (FLOW SWITCH)	1	CWB601008	←	O
6	FLARE NUT (3/8)	1	CWT251061	←	
7	FLARE NUT (5/8)	1	CWT251064	←	
9	PUMP	1	CWB532096	←	O
10	PACKING (O-RING) I.D 32mm	2	CWB811082	←	
11	PACKING (O-RING) I.D 13.8mm	2	CWB811022	←	
12	RETAINING RING D:22mm	1	CWH581007	←	
16	BOTTLE COMPLETE	1	CWH90C0023	CWH90C0017	
17	HEATER ASS'Y	1	CWA34K1026	CWA34K1025	O
18	SOUND PROOF MATERIAL	1	CWG302595	CWG302575	
19	THERMOSTAT	2/3	CWA151065	←	O
20	ELECTRONIC CONTROLLER-MAIN	1	CWA73C5714	CWA73C5715	O
21	TERMINAL BOARD ASS'Y	1	CWA28K1217	←	
22	TERMINAL BOARD ASS'Y	1	CWA28K1232	←	
25	TERMINAL BOARD ASS'Y	1	CWA28K1229	←	
26	TERMINAL BOARD ASS'Y	1	CWA28K1230	←	
27	ELECTRO MAGNETIC SWITCH	1	K6C1AYY00004	←	O
28	TERMINAL BOARD ASS'Y	1	CWA28K1231	←	
29	RESIDUAL CURRENT CIRCUIT BREAKER	2/3	CWA181005	←	O
30	TRANSFORMER-COMLETE	1	CWA40C1075	←	O
31	SENSOR-COMLETE	1	CWA50C2762	←	O
32	REMOTE CONTROL COMPLETE	1	CWA75C3592	←	O
33	PRESSURE GAUGE	1	CWB070001	←	O
34	PRESSURE RELIEF VALVE	1	CWB621011	←	O
35	CABINET	1	CWE001050A	←	
36	HANDLE	2	CWE161008	←	
37	CABINET FRONT PLATE	1	CWE061265A	←	
38	INSTALLING HOLDER	1	CWH361103A	←	
39	OPERATING INSTRUCTION	1	CWF567973	←	
40	INSTALLATION INSTRUCTION	1	CWF614802	←	
41	ACCESSORY-COMLETE (DRAIN ELBOW)	1	CWH82C1763	←	
42	ACCESSORY-COMLETE	1	CWH82C1754	←	
43	FLARE NUT	1	CWT251063	←	
44	FLARE NUT	1	CWT251079	←	

(Note)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.